



Fernsehergeräte - getestet für das Sky CI Plus Modul

Hersteller	Modellbezeichnung	Bildschirmdiagonale		Bemerkung
		cm	Zoll	
LOEWE ART				
Loewe	ART 32 LED	81	32	Ankelnummern 50412080, 50412780, 50412W80, 50412T81, 50412W81, 50412081, 50412T45, 50412W45, 50412045
Loewe	ART 32 LED DR+	81	32	Ankelnummern 50412047, 50412747, 50412W47
Loewe	ART 32 SL	81	32	Ankelnummern 68401W80, 68401T80, 68401U80
Loewe	ART 32 SL DR+	81	32	Ankelnummern 68401W49, 68401T49, 68401U49
Loewe	ART 37 LED	94	37	Ankelnummern 50413080, 50413T80, 50413W80
Loewe	ART 37 LED DR+	94	37	Ankelnummern 50413047, 50413T47, 50413W47
Loewe	ART 37 SL	94	37	Ankelnummern 68423W70, 68423T70, 68423U70
Loewe	ART 37 SL DR+	94	37	Ankelnummern 68423W39, 68423T39, 68423U39
Loewe	ART 40	98	39	Ankelnummern 52433085, 52433T85, 52433U85, 52435W85, 54457T80, 54457W80, 54457U80, 54457T87, 54457U87
Loewe	ART 40 LED 200	101	40	Ankelnummern 50414080, 50414T80, 50414W80
Loewe	ART 40 LED 200 DR+	101	40	Ankelnummern 50414047, 50414T47, 50414W47
Loewe	ART 40 3D	101	40	Ankelnummern 51413T80, 51413W80, 51413080, 51413T47, 51413W47, 51413047
Loewe	ART 42 SL	106	42	Ankelnummern 68402W70, 68402T70, 68402U70
Loewe	ART 42 SL DR+	106	42	Ankelnummern 68402W39, 68402T39, 68402U39
Loewe	ART 46 LED 200	117	46	Ankelnummern 50416080, 50416T80, 50416W80
Loewe	ART 46 LED 200 DR+	117	46	Ankelnummern 50416047, 50416T47, 50416W47
Loewe	ART 47 SL	119	47	Ankelnummern 68403W70, 68403T70
Loewe	ART 47 SL DR+	119	47	Ankelnummern 68403W39, 68403T39
Loewe	ART 48	122	48	Ankelnummern 54458W87, 54458T87, 54458U87
Loewe	ART 50	127	50	Ankelnummern 52436085, 52436T85, 52436U85, 52436W85
Loewe	ART 55	140	55	Ankelnummern 54459T80, 54459T81, 54459W80, 54459W81, 54459W87, 54459T87, 54459U87
Loewe	ART 60	152	60	Ankelnummern 52437085, 52437T85, 52437U85, 52437W85
LOEWE bild				
Loewe	Loewe bild 1.55	140	55	Ankelnummern 55402W89
Loewe	Loewe bild 1.65	164	65	Ankelnummern 56407W87
Loewe	Loewe bild 3.40	102	40	Ankelnummern 56458D80, 56458S80
Loewe	Loewe bild 3.40 dal	102	40	Ankelnummern 56458D82, 56458S82
Loewe	Loewe bild 3.48	122	48	Ankelnummern 56459D80, 56459S80
Loewe	Loewe bild 3.48 dal	122	48	Ankelnummern 56459D82, 56459S82
Loewe	Loewe bild 3.55	140	55	Ankelnummern 56460D80, 56460S80
Loewe	Loewe bild 3.55 dal	140	55	Ankelnummern 56460D82, 56460S82
Loewe	Loewe bild 5.40	102	40	Ankelnummern 56427D50, 56427S50, 56427O50, 56427D30
Loewe	Loewe bild 5.48	122	48	Ankelnummern 56430D50, 56430S50, 56430O50
Loewe	Loewe bild 5.55	140	55	Ankelnummern 56428D50, 56428S50, 56428O50, 56435D50
Loewe	Loewe bild 7.55 Set	140	55	Ankelnummern 56435D00
Loewe	Loewe bild 7.65	164	65	Ankelnummern 56436D50, 56436D30
Loewe	Loewe bild 7.65 Set	164	65	Ankelnummern 56436D00
Loewe	Loewe bild 7.77	195	77	Ankelnummern 56437D50
Loewe	Loewe bild 9.55	140	55	Ankelnummern 56440D50
Loewe	Loewe bild 9.65	164	65	Ankelnummern 56441D50
LOEWE CONNECT				
Loewe	CONNECT 22 SL	54	22	Ankelnummern 50405T80, 50405W80, 50405U80
Loewe	CONNECT 26 SL	66	26	Ankelnummern 50401T80, 50401W80, 50401U80
Loewe	CONNECT 26 LED	66	26	Ankelnummern 50428T80, 50428W80, 50428U80
Loewe	CONNECT 32	81	32	Ankelnummern 68417W75, 68417T75, 68417U75, 68417T70, 68417U70
Loewe	CONNECT 32 3D	81	32	Ankelnummern 51408T82, 51408W82, 51408U82, 51408T42, 51408W42, 51408U42
Loewe	CONNECT 32 LED	81	32	Ankelnummern 50402T82, 50402W82, 50402U82
Loewe	CONNECT 32 LED DR+	81	32	Ankelnummern 50402T42, 50402W42, 50402U42
Loewe	CONNECT 32 MEDIA	81	32	Ankelnummern 68417W76, 68417T72, 68417U72, 68417U76, 68417T72, 68417T76
Loewe	CONNECT 32 MEDIA DR+	81	32	Ankelnummern 68417T31, 68417T32, 68417W31, 68417W32, 68417U31, 68417U32
Loewe	CONNECT ID 32	81	32	Ankelnummern 51462W84, 51462Y84, 51462T84, 51462R84, 51462G84, 51462B84, 51462Z84, 51462J84, 51462F84, 51462P84, 51462H84, 51462J84
Loewe	CONNECT ID 32 DR+	81	32	Ankelnummern 51462W44, 51462Y44, 51462T44, 51462R44, 51462G44, 51462B44, 51462Z44, 51462J44, 51462F44, 51462P44, 51462H44, 51462J44, 51462K44
Loewe	CONNECT 37	94	37	Ankelnummern 68435W70, 68435T70, 68435U70, 68435T75
Loewe	CONNECT 37 MEDIA	94	37	Ankelnummern 68435U72, 68435T72, 68435U76, 68435T72
Loewe	CONNECT 37 MEDIA DR+	94	37	Ankelnummern 68435T32, 68435W31, 68435W32, 68435U31, 68435U32
Loewe	CONNECT 40 LED 200	101	40	Ankelnummern 50404T82, 50404U82, 50404W82
Loewe	CONNECT 40 LED 200 DR+	101	40	Ankelnummern 50404T42, 50404U42, 50404W42
Loewe	CONNECT 40 3D	101	40	Ankelnummern 51409T82, 51409W82, 51409U82, 51409T42, 51409W42, 51409U42
Loewe	CONNECT ID 40	101	40	Ankelnummern 51463W84, 51463Y84, 51463T84, 51463V84, 51463G84, 51463B84, 51463Z84, 51463J84, 51463F84, 51463P84, 51463H84, 51463J84, 52463F85, 52463O85, 52463T85, 52463U85, 52463W85, 52463P85, 52463V85, 52463Y85, 52463Z85
Loewe	CONNECT ID 40 DR+	101	40	Ankelnummern 51463W44, 51463Y44, 51463T44, 51463V44, 51463G44, 51463B44, 51463Z44, 51463J44, 51463F44, 51463P44, 51463H44, 51463J44, 52463F44, 52463O44, 52463T44, 52463U44, 52463W44, 52463P44, 52463V44, 52463Y44, 52463Z44, 52463J44, 52463F44, 52463P44, 52463V44, 52463W44, 52463Y44, 52463Z44
Loewe	CONNECT 40	101	40	Ankelnummern 54445O50, 54445T50, 54445W50, 54445W57, 54445T57, 54445O57
Loewe	CONNECT 42	106	42	Ankelnummern 68436W70, 68436T70
Loewe	CONNECT 42 MEDIA	106	42	Ankelnummern 68436W72, 68436U72, 68436T72
Loewe	CONNECT 42 MEDIA DR+	106	42	Ankelnummern 68436T32, 68436W32, 68436U32
Loewe	CONNECT ID 46	117	46	Ankelnummern 51464Z84, 51464J84, 51464F84, 51464P84, 51464H84, 51464J84, 52464F85, 52464J85, 52464O85, 52464P85, 52464T85, 52464U85, 52464V85, 52464W85, 52464Y85, 52464Z85
Loewe	CONNECT ID 46 DR+	117	46	Ankelnummern 51464W44, 51464Y44, 51464T44, 51464V44, 51464G44, 51464B44, 51464Z44, 51464J44, 51464F44, 51464P44, 51464H44, 51464J44, 52464F44, 52464O44, 52464T44, 52464U44, 52464V44, 52464W44, 52464Y44, 52464Z44, 52464J44, 52464F44, 52464P44, 52464V44, 52464W44, 52464Y44, 52464Z44
Loewe	CONNECT 48	122	48	Ankelnummern 54444W57, 54444T57, 54444O57
Loewe	CONNECT ID 55	140	55	Ankelnummern 51465F84, 51465O84, 51465H84, 51465E84, 51465J84, 51465P84, 51465T84, 51465U84, 51465V84, 51465W84, 51465Y84, 51465Z84, 52465F85, 52465O85, 52465T85, 52465U85, 52465W85, 52465P85, 52465V85, 52465Y85, 52465Z85
Loewe	CONNECT ID 55 DR+	140	55	Ankelnummern 51465F44, 51465G44, 51465H44, 51465I44, 51465J44, 51465P44, 51465T44, 51465U44, 51465V44, 51465W44, 51465Z44, 52465F44, 52465O44, 52465P44, 52465Q44, 52465R44, 52465S44, 52465T44, 52465U44, 52465V44, 52465W44, 52465X44, 52465Y44, 52465Z44
Loewe	CONNECT 55	140	55	Ankelnummern 54443O50, 54443O51, 54443T50, 54443T51, 54443W50, 54443W51, 54443Y57, 54443Z57, 54443O57



Fernsehgeräte - getestet für das Sky CI Plus Modul

Hersteller	Modellbezeichnung	Bildschirmdiagonale		Bemerkung
		cm	Zoll	
LOEWE INDIVIDUAL				
Loewe	INDIVIDUAL 32 COMPOSE Sound LED D	81	32	Artikelnummern 69415B47, 69415L47, 69415U47
Loewe	INDIVIDUAL 32 COMPOSE Sound LED 3	81	32	Artikelnummern 51425B47, 51425L47, 51425U47
Loewe	INDIVIDUAL 32 SELECTION	81	32	Artikelnummern 69401N70, 69401V70, 69401B70, 69401U70
Loewe	INDIVIDUAL 32 SELECTION DR+	81	32	Artikelnummern 69401N39, 69401V39, 69401B39, 69401U39
Loewe	INDIVIDUAL 32 SELECTION Sound LED	81	32	Artikelnummern 69415B80, 69415L80
Loewe	INDIVIDUAL 40	101	40	Artikelnummern 52401B43, 52401L43, 52401P43, 52401U43, 52401B41, 52401L41, 52401U41, 52401P41
Loewe	INDIVIDUAL 40 COMPOSE DR+	101	40	Artikelnummern 67437L36, 67437B36, 67437U36
Loewe	INDIVIDUAL 40 COMPOSE LED 400 DR+	101	40	Artikelnummern 69408B44, 69408B48, 69408L44, 69408L48, 69408U44, 69408U48
Loewe	INDIVIDUAL 40 COMPOSE 3D	101	40	Artikelnummern 50430B48, 50430L48, 50430U48, 50430B44, 50430L44, 50430U44
Loewe	INDIVIDUAL 40 SELECTION	101	40	Artikelnummern 67442V70, 67442N70, 67442B70, 67442U70
Loewe	INDIVIDUAL 40 SELECTION DR+	101	40	Artikelnummern 67442V37, 67442B37, 67442N37, 67442U37
Loewe	INDIVIDUAL 40 SELECTION LED 200	101	40	Artikelnummern 69418B80, 69418L80
Loewe	INDIVIDUAL 40 SELECTION LED 200 DF	101	40	Artikelnummern 69418B47, 69418L47, 69418U47
Loewe	INDIVIDUAL 46	117	46	Artikelnummern 52402B43, 52402L43, 52402P43, 52402U43, 52402B41, 52402L41, 52402U41, 52402P41
Loewe	INDIVIDUAL 46 COMPOSE DR+	117	46	Artikelnummern 67439B36, 67439L36
Loewe	INDIVIDUAL 46 COMPOSE LED 400 DR+	117	46	Artikelnummern 69409B44, 69409B48, 69409L44, 69409L48, 69409U44, 69409U48
Loewe	INDIVIDUAL 46 COMPOSE 3D	117	46	Artikelnummern 50431B48, 50431L48, 50431U48, 50431B44, 50431L44, 50431U44
Loewe	INDIVIDUAL 46 SELECTION	117	46	Artikelnummern 67443B75, 67443N75
Loewe	INDIVIDUAL 46 SELECTION DR+	117	46	Artikelnummern 67443B37, 67443N37, 67443U37
Loewe	INDIVIDUAL 46 SELECTION LED 200	117	46	Artikelnummern 69419B80, 69419L80
Loewe	INDIVIDUAL 46 SELECTION LED 200 DF	117	46	Artikelnummern 69419B47, 69419L47, 69419U47
Loewe	INDIVIDUAL 52 COMPOSE DR+	132	52	Artikelnummern 67440L36, 67440B36, 67440U36
Loewe	INDIVIDUAL 55	140	55	Artikelnummern 52403B43, 52403L43, 52403P43, 52403U43, 52403B41, 52403L41, 52403U41, 52403P41
Loewe	INDIVIDUAL 55 COMPOSE LED 400 DR+	140	55	Artikelnummern 69410B48, 69410L48, 69410U48
Loewe	INDIVIDUAL 55 COMPOSE 3D	140	55	Artikelnummern 50432B48, 50432L48, 50432U48
LOEWE MODUS				
Loewe	MODUS 32	81	32	Artikelnummern 69403D70, 69403D75, 69403A70, 69403A75
Loewe	MODUS 37	94	37	Artikelnummern 69404D70, 69404A70
LOEWE One				
Loewe	One 55	140	55	Artikelnummern 55402W88
LOEWE REFERENCE				
Loewe	Reference ID 40	101	40	Artikelnummer 52421B43
Loewe	Reference ID 46	117	46	Artikelnummer 52422B43
Loewe	Reference ID 52	132	52	Artikelnummer 68426B48
Loewe	Reference ID 55	140	55	Artikelnummern 52424B42, 52424B43, 52424B41, 54433B47, 54433L47, 54433U47; 54433K47
Loewe	Reference ID 75	189	75	Artikelnummern 54434B47, 54434L47, 54434U47
Loewe	Reference ID 85	216	85	Artikelnummern 54435B47, 54435L47, 54435U47
LOEWE XELOS				
Loewe	XELOS 32	80	32	Artikelnummern 51429W81, 51429T81, 51429O81, 51429U81, 51429W80, 51429T80
Loewe	XELOS 32 LED	81	32	Artikelnummern 50422T80, 50422W80
Loewe	XELOS 32 MEDIA	81	32	Artikelnummern 50422T81, 50422W81
Loewe	XELOS 32 SL	81	32	Artikelnummern 69413W70, 69413W80, 69413T70, 69413T80
Loewe	XELOS 32 SL DR+	81	32	Artikelnummern 69413W49, 69413T49
Loewe	XELOS A 32	81	32	Artikelnummern 69402D70, 69402T70, 69402V70
Loewe	XELOS A 32 DR+	81	32	Artikelnummern 69402D39, 69402T39, 69402V39
Loewe	XELOS 37 SL	94	37	Artikelnummern 69414W70, 69414W80, 69414T70, 69414T80
Loewe	XELOS 37 SL DR+	94	37	Artikelnummern 69414W49, 69414T49
Loewe	XELOS 40	101	40	Artikelnummern 51439T80, 51439W80, 51439O80, 51439U80
Loewe	XELOS 40 LED	101	40	Artikelnummern 50424T80, 50424W80
Loewe	XELOS 40 MEDIA	101	40	Artikelnummern 50424T81, 50424W81, 50424T83, 50424W83
Loewe	XELOS 42 SL	106	42	Artikelnummern 69416W80, 69416T80
Loewe	XELOS 42 SL DR+	106	42	Artikelnummern 69416W49, 69416T49
Loewe	XELOS 46	117	46	Artikelnummern 52449T80, 52449W80, 52449O80, 52449U80